D. P. Lube ALD600/900 Series

- Centralized control of multi-point lubrication
- Low oil consumption volume
- Simplified oil feeding volume setting in which only the pressure differential is adjusted.
- Oil can be replenished by merely opening and closing the oil filler plug without stopping the air line.
- The condition of the generation of micromist can be checked from the oil filler port.







ALDU600 (with panel)

Float Switch Specifications

Voltage	200 VAC, 200 VDC				
Max. contact capacity	50 VA AC, 50 W DC				
Max. operating current	0.5 A AC, 0.5 A DC				
Contact point construction	1a, 1b				
Level indication	Bottom limit indication				

Standard Specifications

Model name	D.P.	Lube	D.P. Lube Unit Note 1)							
Model	ALD600	ALD900	ALDU600	ALDU900						
Port size Note 2)	^{3/4} 1	11/4 11/2 2	^{3/4} 1	11⁄4 11⁄2 2						
Fluid	Air									
Proof pressure	1.5 MPa									
Operating pressure range	0.1 to 1.	0 MPa	0.15 to	1.0 MPa						
Operating pressure differential range	0.03 to 0.1 MPa									
Recommended press. differential		0.05	MPa							
Press. differential setting min. flow Note 3)		102 L/m	in (ANR)							
Bowl capacity between levels (cm ³)	2000	5000	2000	5000						
Recommended lubricant	Turbine o	il Class 1(With	no additives), I	SO VG32						
Ambient and fluid temperature	5 to 60°C									
Bowl material	Epoxy	resin with glas	s fiber, Polycar	bonate						
Weight (kg)	8.9	8.9 21.3 11.1 (18.6)								

Note 1) D.P. Lube unit has an attached filter at primary side of D.P. Lube. Note 2) Port of D.P. Lube unit is union.


Note 2) Port of D.P. Lube unit is union. Note 3) Condition: Inlet pressure = 0.5 MPa, Pressure differential = 0.05 MPa

Note 4) () is weight with panel.


Accessory (Option) Part No.

\sim		Part no.								
Description Model		ALD600	ALD600 ALD900 ALDU600		ALDU900					
Bracket		126130P	126044P	126130P	126044P 113449 Note 1) 113543 Note 2)					
Panel			—	12661P	12651-1P					
Float switch	S1	IS430-1	IS420-1	IS430-1	IS420-1					
Float Switch	S2	IS430-2	IS420-2	IS430-2	IS420-2					

Note 1) Bracket for filter mounting: For Rc $1\frac{1}{4}$, $1\frac{1}{2}$ Thread machining on filter body is needed. Note 2) Bracket for filter mounting: For Rc 2



Piping Example




How to read the graph (Example)

n


When the inter pressure is 0.5 MPa, a flow rate that is greater than 102 L/min(ANR) will be necessary to set the pressure differential to 0.05 MPa. Below this flow rate, the pressure differential cannot be set to 0.05 MPa.


ALD600/900 Series

Construction



ALD900





Component Parts

No.	Description	Material							
No. Descriptio	Description	ALD600	ALD900						
1	Body	Aluminum die-casted	Aluminum casted						
2	Bottom cover	Aluminum die-casted	Aluminum casted						

Replacement Parts

No.	Description	Material	Par	t no.		
INO.	No. Description	Material	ALD600	ALD900		
3	Check valve assembly	—	12612AP	—		
4	Pilot body assembly	_	_	12609AP		
5	Bowl assembly	Glass fiber-inserted epoxy resin	126139-1A	126059-1A		
6	Lubrication plug assembly	Zinc die-casted, NBR	126115AP	126115AP		
7	Pressure gauge (2 pcs.)	-	GA46-10-01	GA46-10-02		
8	Bowl assembly	-	AF11-3	AF11-3		
9	Seal (2 pcs.)	NBR	126140	126060		
10	O-ring	NBR	11307	11307		
11	Seal	NBR	—	126046		
12	Seal	NBR	126047(2)	126047		
13	Check valve assembly (2 pcs.)	_	126127A	126022A		
14	Filter element	Bronze	11294-70B	11294-70B		

Precautions Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Precautions on every series. Caution on Design

∆Warning

 Epoxy resin containing glass fiber and polycarbonate is used in some parts of the D.P. Lube and the D.P. Lube Unit. These units cannot be used in an environment or in a location that is exposed to synthetic oil, thinner, acetone, alcohol, organic solvents such as ethylene chloride, chemicals such as sulfuric acid or nitric acid, cutting oil, kerosene, gasoline, or a threadlock agent, etc., because they will be damaged.

Mounting/Adjustment

- Provide about 30 cm of space above and below the D.P. Lube or the D.P. Lube Unit to facilitate their maintenance and inspection.
- When the line is stopped, do not adjust or set the differenital pressure, as it could cause the differential adjustment valve to break.
- When setting the pressure differential, if there is a fluctuation in the operating flow rate, set the pressure differential at the lower flow rate range.

Piping

∆Warning

- The drain pipe for the air filter in the D. P. Lube Unit must have a minimum pipe bore of ø6.5, and a maximum length of 5 m. Avoid using a riser pipe because it could cause the auto-drain to malfunction.
- If installing an air tank, install it on the IN side of the D.P. Lube Unit. If it is installed on the OUT side, the micromist could be arrested by the air tank, which could lead to insufficient feeding of oil.

Maintenance


∆Warning

 Before removing the oil filler plug, loosen it two and a half turns to completely release the pressure inside the case. This will prevent the oil filler plug from flying out.



D. P. Lube ALD600/900 Series


D.P. Lube/ALD600-06 to 10, ALD900-12 to 20



AL800 Al900
ALF Alt
ALD
ALB
LMU
ALIP
AEP HEP

Model	Port size			с	D	Е	Bracket dimensions						
woder	Port size	A	в				F	G	н	J	к		
ALD600-06 to 10	³ ⁄4, 1	175	175	87.5	487	135	344	32.5	95	14	55.5		
ALD900-012 to 20	11/4, 1/2, 2	250	250	125	639	210	416.5	0	120	14	48		

D.P. Lube Unit/ALDU600-06 to 10, ALDU900-12 to 20





Model	Port size	A	в	с	D	Е	F	G	н	J	к	L	м	N	Р	Q	R	s						
ALDU600-06	3/4	470	470	430	20	500	150	00	90 145	145	145	145	145	145	487	344	55.5	24.5	69.5	289	175	87.5	30	62.5
ALDU600-□10	1	470	430	20	500	150	90	145	145 467	07 344	55.5	13.6	78.2	291.2	1/5	07.5	30	02.5						
ALDU900-012	11/4								639			51	89	453										
ALDU900-014	11/2	250	250	125	639	9 230	230 120	227	227 639	639 416.5	416.5 48	45.5	94.5	453	250	125	33.2	33.2						
ALDU900-020	2										639			14.5	102.5	476								

ALD600/900 Series

Related Products: Strainer

At the terminal of an air pressure line in which a D.P. Lube is used, install a strainer (filtration rate of 5 µm) upstream with a metal seal solenoid valve, which is susceptible to dust.





Model	A	с	D	Е	F	G	н	J	к
AF30-02 to 03-X2230	Rc 1/4, 3/8	53	118	14	53	57	35	44	M4 x 0.7 x 0.5
AF40-02 to 04-X2230	Rc 1/4, 3/8, 1/2	70	165	18	70	73	47	60	M5 x 0.8
AF40-06-X2230	Rc 3/4	75	169	20	70	73	47	60	M5 x 0.8
AF50-06 to 10-X2230	Rc 3/4, 1	90	245	24	90	—	59	73	M6 x 1
AF60-10-X2230	Rc 1	95	258	24	95	-	63	78	M6 x 1